

Botley Market Hall



ACTIVITY ROOM ,THE HUB & STAIRWELL CORRIDOR

The heating is set to come on between 8 am to 10am and 5pm to 8pm . Outside of these hours if it is too cold please activate the Booster button located in the



The Booster is a simple push button electronic timer that saves energy by remembering to switch off an appliance when you might forget!

The switch offers preset time periods ranging from
30 minutes, 60 minutes or 120 minutes.

Simply press the boost button and walk away.

Press the BOOST button in quick succession
until the indicator light for the required boost period is illuminated

To cancel a boost period, press the BOOST button continuously.
Keeping the boost button depressed will cancel any boost period.
When the boost is activated the indicator lights will 'countdown'
showing the approximate duration of the boost period remaining