

Farnham Village Hall – PA System Guide



The cabinet door key is on the village hall keyring.

If the system is to be used for more than one hour, remove the locked side panels to allow good ventilation as the units will get very hot.

1. Turn on electricity at socket below the music rack

2. Bluetooth enablement:

Press the right-hand button on the BL Bluetooth box and (if your device has not previously been 'paired' with this system) hold for 5 seconds. You'll hear a sound and the small blue light will come on. This allows your device to be paired – look for Music BT01. Once paired you can play downloaded or stream music (Wi-Fi network TNCAP8054AB, code kr9rqc4RJ4cGnLyX) with volume control via your personal device.

If you've already used the system, initially hold down the right hand button for 3 seconds and again you'll hear a sound and your device will be ready for use (as above).

There is also an auxiliary cord socket available on the BT Bluetooth box for wired connections.

Remember to disconnect your device when finished.

3. Microphone Use:

There are two handheld battery-operated microphones on the top shelf in the music cabinet.

These are already tuned into the system and ready to go once the individual microphone has been switched on. Both can work in tandem but not simultaneously (one will over-ride the other). You can speak 'over' the music being played and they should operate anywhere within the main hall.

Turn off the microphones when not in use.

4. When finished, ensure microphones are turned off and returned to top shelf, the side panels (if removed) are replaced the door is locked and electricity turned off.